



Cleaning- and care instruction for oiled and waxed floors

To protect your floors for a long time, it's important to clean correctly and periodically and keep them in good condition!

In principle the floors have to be cleaned dry with a broom or a vacuum cleaner.

A damp cleaning should only be done, if it is really necessary. To do a correct cleaning, two bucket are needed. In one of them put water and our special cleaner for oiled and waxed floors. In the other put only water. The bucket with water alone is only for cleaning the wiper rag.

First put the wiper rag in the bucket with water and cleaner, wipe a part of the floor and clean the wiper rag in the bucket with water. Then start this procedure till the whole floor is clean.

Don't take only one bucket with water, because you will distribute the dirt with the dirty water all over the whole floor!

The first cleaning should be done, after 8 – 10 days, when the works are finished, and the oil or/and wax is hard and completely dry. Take 500 – 750 millilitre NaturProfi Wischpflege for 8 litre water at the first cleaning (only the first cleaning!). With the following cleanings take only **150 – 200** millilitre for 8 litre water.

The responsible persons are informed about the correct use of our NaturProfi Wischpflege and NaturProfi Pflegeöl.

If there will be bigger damages or a new oiling/waxing is necessary, you have to contact the joiner.

To secure an efficient cleaning for your floors, it makes sense to prepare a cleaningplan, so that very frequented floors will be better protected and less frequented parts will not be "broken-cleaned"!

Technical information about the products are handed to the architect, cleaning-staff and personnel from the house.

For the attention

House management / Technical Service / Caretaker:

Architect:

Joiner and staff

Chief of cleaning-staff